



HP StorageWorks Secure Path



Supported Single Path Connections

- Non-Mission Critical Servers
- Zoning required to isolate the single path hba to one or (with OpenVMS or Tru64) two hsv controller ports.
- → General limitations:
 - No support for Windows 2000 DC


 - No boot support (most OS's)
 - ↓ No cluster support (most OS's)
- Single Path Implementation Whitepaper available at http://h18006.www1.hp.com/storage/arraywhitepapers.html.



Multi Path Strategy - Objectives


- Eliminate requirement for proprietary multi path solutions
- Reduce Total Cost of Ownership for High Availability applications
- √Provide consistent multi path solutions across HP array family (MSA, EVA, XP)
- √See

http://h18006.www1.hp.com/products/sanworks/multipath options/index.html for updated information



Path failover vs Secure Path

- Zurrent support for Linux and Windows 2003 with limited configurations and hba's
- 7 No Gui or management interface or Rolling Upgrades
- No load balancing
- No support for added value software (ie, Business Copy or Continuous Access)




StorageWorks Secure Path Overview

Secure Path Overview


- Current Products
- http://h18006.www1.hp.com/products/sanworks/securepath/index.html

Secure Path Specifics


- Windows
- Netware
- Sun
- IBM
- HP-UX




Secure Path Overview




Server




- •HBA fails data rerouted to 2nd HBA
- •Controller or port fails data rerouted to 2nd port or controller
- ·Can be used for load balancing



Storage System






What is Secure Path?

Current platform support

- ↓ HP StorageWorks Secure Path v4.0C for Windows
- HP StorageWorks Secure Path v4.0C for Windows Workgroup Edition
- ↓ HP StorageWorks Secure Path v3.0C for SUN Solaris
- → HP StorageWorks Secure Path v3.0D for HP-UX
- → HP StorageWorks Secure Path v2.0D for IBM-AIX
- ↓ HP StorageWorks Secure Path v3.0C for NetWare
- HP StorageWorks Secure Path v3.0C for NetWare Workgroup Edition
- ↓ HP StorageWorks Secure Path v3.0℃ for Linux
- HP StorageWorks Secure Path v3.0C for Linux Workgroup Edition




What is Secure Path?

¬ hosts supported


- → HP-UX v11.0, v11i (32/64 bit mode), 11.23 for XP, EVA, VA
 - ↓ ServiceGuard
- Microsoft Windows Server 2003 (Standard and Enterprise), Windows NT v4, Windows 2000, Datacenter
 - ↓ MSCS, OPS, 9iRAC
- ↓ IBM-AIX v4.3.3, v5.1, 5.2
 - **↓** HACMP
- ↓ SUN Solaris v2.6, v7, v8, v9 (32/64 bit mode)
 - Veritas, Sun Cluster Server
- → RH Linux Advanced Server 2.1, 3.0. United Linux 1.0/SLES 8.0. Check quickspecs for kernel errata.
 - √ SteelEye, ServiceGuard, 9iRAC

- ↓ HP StorageWorks EVA
- → HP StorageWorks msa1000, msa1500
- → HP StorageWorks MA/EMA
- → HP StorageWorks ra4000, ra4100




What is Secure Path

- Secure Path is an Application that adds an Operating System Feature called "Multi-Path Capability"
- Multi-Path Capability works in conjunction with the Storage Array Feature called "Multibus Failover Mode"
- Jose Operating Systems like OpenVMS and Tru64 UNIX V5.x have Multi-Path Capability built into the OS and do not need a "Secure Path" Application.




What Is Secure Path

- NT 4.0, Windows 2000, Sun Solaris, AIX and other OS's <u>need</u> Secure Path in order to take advantage of Multibus Mode in a storage array.
- Multi-Path Capability and Multibus Mode combined gives the OS the capability of Path Failover
- Supports Fibre Channel and UltraSCSI (WNT=Z70, Sun=Z80)
- → Simple Software Installation procedure




What is Secure Path

- 7 Eliminates the I/O bus as a single point of failure
- □ Local & Remote Management via TCP/IP (Windows, Netware)
- □ I/O Performance Considerations
 - Dynamic load distribution across both controller host ports of the same controller
 - · Manual load balance across adapters / buses
 - · Manual load balance across RAID controllers
 - Manual load balance across hosts (MSCS)
- → Device Management to balance I/O




What is Secure Path

- Requires redundant host bus adapters and cabling for fully redundant operation.
- Requires Storage to be set to Multibus Failover.
- Secure Path is one component in a high availability solution and can be used in:
 - Standalone Configurations
 - MSCS Clusters
 - Disaster Tolerant Solutions
 - · SAN Configurations
 - OPS Configurations




Theory of Operation

- Tenables dual StorageWorks RAID controllers to operate in an active/active implementation
- → Storage controller
 - ↓ Set PREFERRED_PATH attribute
 - → Move storage units between paths with management utility.
 - ↓ Secure Path controls ports through which storage unit is presented
- Secure Path detects I/O failure and automatically reroutes traffic to other available paths
 - ↓ Seeks alternate paths through available SCSI buses, Fibre Channel switches, controllers and ports, and HBAs
- 7 Management utility can fail back to original path



Current Architectures


- Separate development on different platforms has lead to a series of cross platform differences.
 - Different driver implementations
 - Different set of features
 - Different behaviors for some features
 - Different solutions for the same problems



Secure Path Architecture


→ Software Components


- ↓ Secure Path Setup Utility
 - Driver installation and removal
 - Check required components prior to installation
- ↓ Secure Path Driver
 - Filter driver for multiple-bus operation
- ↓ Secure Path Agent
 - Enables communication between driver and Secure Path Manager
- ↓ Secure Path Management
 - Manages paths



Current Architecture - Windows


- Multi-path support
- 7 Layered driver
- Web based application for management
- Event notification to management application
- 7 Current version is 4.0C
- http://h18006.www1.hp.com/products/sanworks/ secure-path/spwin.html






Current Architecture - Solaris

- Multiple-path support
- 7 Layered driver
- 7 Command line management interface
- → Event notification via email





Secure Path for Solaris

- ↓ swsp driver Failover driver presented as pseudo-HBA
 driver to SCSI disk drivers
 - Presents multiple paths as single device
 - Initiates path failover
- hsx driver Provides paths from HBA driver for specific arrays to swsp
 - Manages separate paths to a LUN
 - Supports HSG and EVA controllers
- ↓ path driver Allows hsx and swsp to communicate in the kernel




Secure Path for Solaris






Current Architecture - HP-UX

- Multiple-path support
- 7 Layered driver
- 7 Command line management interface
- → Event notification via email





Secure Path for HP-UX

- swsp driver Failover driver presented as a pseudo-HBA driver to SCSI disk drivers
 - Presents multiple paths as a single device to the host SCSI disk driver
 - Initiates path failover when necessary and manages all kernel threads related to failover.
- hsx driver Provides paths from an HBA driver for specific arrays up swsp driver
 - Manages separate paths to a LUN and encapsulates array-specific knowledge.
 - Supports HSG and EVA controllers



Secure Path for HP-UX






Secure Path for AIX


7 hdisk

- ↓ SCSI and FC disk driver
- Installs at boot or during cfgmgr operations

₱ PC1000SP


- HBA driver that manages multiple adapters
- Enables the AIX system to perform failover
- Used with the Secure Path
 Status and Management
 Utility (cbxfcsm)






Current Architecture - Novell

- Multi-path support
- → Layered driver
- Web based application for management
- 7 Event notification to management application




- → Windows
- → NetWare
- **对 Solaris**
- → HP-UX




Windows

- ↓ Windows service
- ↓ Using TCP/IP and Winsock communicates with
 - Secure Path driver
 - Secure Path Manager
- Posts errors and information to application event log




NetWare

- → NetWare Loadable Module (hpqspagt.nlm)
- ↓ Communicates with q12300.ham and HPQSP.CDM drivers
- ↓ Communicates with Secure Path Manager
- ↓ The HPQSP.CDM driver provides the primary failover capability in the Secure Path product.




7 Sun Solaris

- ↓ spagent—daemon process
 - Logs event to console and system log
 - Can run in single-user mode
 - Sends email notification
- ↓ Transparent to applications
- Only supported method to start/ stop SP agent spinit command




⊅HP-UX

- ↓ spagent—daemon process
 - Interface for SP applications and utilities to communicate to multipath drivers
 - Provides notification of path change events through email
 - Not required to be running for SP drivers to configure and provide failover
 - Must be running for email notification
- → Only supported method to start/ stop SP agent spinit command




Secure Path Management

- 7 Windows and Netware
 - ↓ Secure Path Manager
- - ↓ Command line



Windows/NetWare

- ↓ Installed on Appliance or standalone server
- Web-based cross-platform SP configuration utility
- ↓ Multiple path configurations
- ↓ Enables
 - Continuous availability of storage systems
 - Display of current path states
 - Remote notification of critical events
 - Ability to select load distribution policy




→ Element Manager

- ↓ Component of SPM communicates directly with SP agents
- Client/server application manages multi-path Array configurations
- ↓ Graphical representation of multi-path environments
 status
- Local to managed servers or remote at management workstation

¬Notification Utility

alerts designated recipients to Secure Path Manager events




7 Sun Solaris

- y spmr Manages paths, displays status, and permits CLI
 access to the controller
- ↓ spconfig Manages spagent that detects path event and sends an email notification


JIBM AIX

- ↓ Cbxfcsm utility that
 - Displays information
 - Moves a LUN from one path to another (load balancing, etc)
 - Transitions path to online or standby state



7HP-UX


- ▼ spmgr Utility that monitors and manages devices, storage systems, paths to units in a SP configuration
 - Lets you modify the configuration to repair, replace, or reconfigure
 - Relies on spagent to handle calls to the driver (swsp)
- ↓ spagent Interface for SP applications to communicate
 with SP drivers
 - spagent is started at system boot time
 - Must be running for the spmgr utility to operate.
- ↓ spinit Script that starts/stops SP agent




profiles

Manage configurations with single instance of SPM

- Managed entity or profile
- Maximum 128 servers sharing up to 128 storage systems
 - Configure and connect storage system in multi-bus failover
 - Host systems standalone servers or clusters
- ↓ Multiple profiles






interpreting path status

7 Modes

- Preferred Paths user-specified paths for host to storageset communication
- Alternate Paths redundancy when the preferred paths fail
- Two offline modes
 - Includes original mode and indicates user specified that path should never be used for I/O
 - Marked offline by user


7State

- Active currently servicing or capable of servicing I/O
- Available belongs to the set of redundant storageset paths that could be used during failover
- Failed path has encountered errors




load distribution

- Multiple paths between host and storageset for parallel I/O
 - ↓ I/O dispatched through appropriate paths
 - ↓ Spreads load across all ports
 - ↓ Three types of load distribution
 - Round
 - Least I/O
 - Least Bandwidth
- Requires a SAN configuration w/4 paths from host storage
- SP marks all paths to owning controller Preferred by default
- 7 User can modify the operational mode of individual paths
- 7 Only available in OS that supports four active ports



path verification

- SP periodically tests viability of all paths to all storagesets
 - ↓ For paths marked Available, Failed, or Active
- Useful for detecting failures that affect overall path redundancy before they affect failover capability
- 7 Path failover occurs if
 - → Preferred path fails path verification
 - → Alternate path fails path verification
- 7 If a path marked Failed passes path verification, the Path State is set to Available
 - ↓ If auto-failback is enabled, the Preferred path becomes Active.




failover hierarchy

Zero Load distribution disabled

- → Preferred-Active path marked as failed—switches to next
 Alternate-Available path on same controller if it exists
- ↓ Attempt to move device to Alternate-Available path on other controller

7 Load distribution enabled


- → Marked path as failed—removes it from usable path list
- ↓ If no Preferred-Active path remaining, uses Alternate-Available path on same controller activated if one exists
- ↓ If no Alternate-Available paths on same controller
 - Attempts to move to an Alternate-Available path on other controller
 - Sets all Alternate-Available paths to Alternate-Active




failback options


Restore load of a failed system component to a replacement

- → Manual mode Devices are restored to their original path either through drag-and-drop operation (controller failback) or action menu items (repair
- ↓ Automatic mode SP tests a failed path at fixed intervals if I/O is in process for device
 - If path viable, Path State is set to Active and I/O routed through this path
 - In automatic failback, with path verification, SP enables failback to be performed automatically even if automatic not selected



Secure Path Manager







i n v e n t